

QUICK REFERENCE

# BATTERY TYPES CHART



Not sure which battery your device takes? Here are the batteries used by the most common APB sensors. Your model number is on a small sticker inside the sensor cover or on the back of the device.

| DEVICE                | BATTERY     | MODEL    | QTY          |
|-----------------------|-------------|----------|--------------|
| Door / Window Sensor  | CR123       | 5816     | 1            |
| Door / Window Sensor  | CR2032      | 5811     | 1            |
| Door / Window Sensor  | AAA Lithium | 5820L    | 1            |
| Recessed Door Sensor  | AAA Lithium | 5818MNL  | 1            |
| PIR Motion Detector   | CR123       | 5890     | 2            |
| Motion Detector       | CR123       | 5800     | 1            |
| Motion Detector       | AA Lithium  | 5898     | 2+           |
| Glass Break Detector  | CR123       | 5853     | 1 (older: 2) |
| Universal Transmitter | CR123       | 5817CBXT | 1            |
| Wireless Key Fob      | CR2032      | 5834     | 1            |
| Panic Button          | CR2032      | 5802WXT  | 1            |
| Smoke Detector        | CR123       | —        | 1 (early: 2) |
| Cellular Communicator | 6V SLA      | GSMV4G   | 1            |

Any Questions? Please give us a call:

**(718) 698-8244**



Some  
type

the wrong